



USE IT



CLEAN IT



USE IT AGAIN

DISASSEMBLE



Remove filters (discard if blocked).



Remove exhalation valve cover



Remove harness



Remove diaphragm

CLEAN



Clean mask body with soapy water



Clean exhalation valve cover



Clean diaphragm



Dry all components

REASSEMBLE



Replace diaphragm



Replace harness



Replace exhalation valve cover



Replace filters (new pair if required).

WATCH THE VIDEO HERE



www.presstocheck.com
www.jspsafety.com
sales@jspsafety.com

Issued: 02/20 Copyright ©2020. JSP Ltd. All Rights Reserved